

CODE:P4032XXItem:Mechanical shear-head connectors medium voltage

INSTALLATION MANUAL

1.	Peel off the insulation from the cables for the appropriate lengthit and clean the conductors with steel brush of dirtiness and/or dust.	
2.	Unscrew bolts of Mechanical shear-head connector to have enough space to place conductors into clamp.	
3.	Place the conductors in the grooves of the connector as shown on the picture. NOTE: use inserts for smaller cable cross - sections. For larger cross - sections, it is not necessary to use inserts (in this case, the cable cannot be placed in the connector with inserts).	SEG
4.	Tighten the bolts of the connector with adequate wrench till shear heads shear from the bolts. This will be adequate tightening torque for the connector.	
5.	Mechanical shear-head connectors medium voltage is now ready for exploitation.	

